ATTENTION



Locomotive Number		Date		last service klms		this service klms		klms travelled	
A=UNFIT FOR SERVICE B= FOR FUTURE				C= FIT FOR SERVICE D= NOT APPLICA					CABLE

	Checklist	Α	В	С	D	Comments/Remarks
1 Sc	ope					see procedure
	eneral					see procedure
3 Sa	fety first					see procedure
	eaning					•
it is t	he responsibility of maintenance personnel to ensure					
	ning of locomotive is to an acceptable standard					
1.	4.1 Cab					
	all foreign materials to be removed from locomotive					
	clean and remove dirt dust grease and oil from cab					
	floors control stands walls and windows					
2.	4.2 Toilet					
	clean using suitable brush					
	ensure floor drains are not blocked					
	fill service water					
3.	4.3 Engine and fan room					
	all foreign materials to be removed from locomotive					
	clean and remove excessive dirt dust grease and oil					
	from engine block floors walls and walkways					
	all cables components devices and equipment are					
	to be clearly visible					
4.	4.4 Battery boxes					
	wash out using soda and hot water					
5.	4.5 Equipment blow out					
	remove covers and examine operation gen field					
	switch off with engine running at idle blow out the					
	following equipment with compressed air					
	control stands					
	compressor intercooler					
	electrical cabinet					
	vigilance control equipment					
	motors (fuel oil pump crankcase exhauster and					
	starter)					
	motors (auxiliary equipment)	<u> </u>				
	auxiliary alternators/generators	ļ				
	alternator slip rings examine for sparking	ļ				
	traction generator	ļ				
	traction motors					



A=UNFIT FOR SERVICE	B= FOR FUTURE ATTENTION	C= FIT FOR SERVICE	D= NOT APPLICABLE
---------------------	----------------------------	--------------------	-------------------

	Checklist	Α	В	С	D	Comments/Remarks
4 Cl	eaning					
	he responsibility of maintenance personnel to ensure ning of locomotive is to an acceptable standard					
6.	4.6 Radiators					
	outside with engine shutdown					
	blow out air passages in reverse air flow direction with compressed air					
	4.7 Underneath locomotive					
7.	4.8 Main reservoir drain cocks					
	drain condensate from all dirt collectors intercoolers and reservoirs					



A=UNFIT FOR SERVICE	B= FOR FUTURE ATTENTION	C= FIT FOR SERVICE	D= NOT APPLICABLE

Checklist A B C D Comments/Rem 5 Pre-inspection 5.1 Defects examination this is a general examination of locomotive cab/s generator room control compartment engine and fan room underframe equipment bogies and brake equipment to locate any broken loose or defective equipment 5.2 Samples and testing 8. 5.3 Crankcase lube oil sample 9. 5.4 Compressor lube oil sample 10. 5.5 Cooling fan hydraulic oil sample (where required) 11. 5.6 Engine coolant sample coolant concentration and conductivity test	narks
this is a general examination of locomotive cab/s generator room control compartment engine and fan room underframe equipment bogies and brake equipment to locate any broken loose or defective equipment 5.2 Samples and testing 8. 5.3 Crankcase lube oil sample 9. 5.4 Compressor lube oil sample 10. 5.5 Cooling fan hydraulic oil sample (where required) 11. 5.6 Engine coolant sample coolant concentration and conductivity test	
this is a general examination of locomotive cab/s generator room control compartment engine and fan room underframe equipment bogies and brake equipment to locate any broken loose or defective equipment 5.2 Samples and testing 8. 5.3 Crankcase lube oil sample 9. 5.4 Compressor lube oil sample 10. 5.5 Cooling fan hydraulic oil sample (where required) 11. 5.6 Engine coolant sample coolant concentration and conductivity test	
generator room control compartment engine and fan room underframe equipment bogies and brake equipment to locate any broken loose or defective equipment 5.2 Samples and testing 8. 5.3 Crankcase lube oil sample 9. 5.4 Compressor lube oil sample 10. 5.5 Cooling fan hydraulic oil sample (where required) 11. 5.6 Engine coolant sample coolant concentration and conductivity test	
underframe equipment bogies and brake equipment to locate any broken loose or defective equipment 5.2 Samples and testing 8. 5.3 Crankcase lube oil sample 9. 5.4 Compressor lube oil sample 10. 5.5 Cooling fan hydraulic oil sample (where required) 11. 5.6 Engine coolant sample coolant concentration and conductivity test	
locate any broken loose or defective equipment 5.2 Samples and testing 8. 5.3 Crankcase lube oil sample 9. 5.4 Compressor lube oil sample 10. 5.5 Cooling fan hydraulic oil sample (where required) 11. 5.6 Engine coolant sample coolant concentration and conductivity test	
5.2 Samples and testing 8. 5.3 Crankcase lube oil sample 9. 5.4 Compressor lube oil sample 10. 5.5 Cooling fan hydraulic oil sample (where required) 11. 5.6 Engine coolant sample coolant concentration and conductivity test	
8. 5.3 Crankcase lube oil sample 9. 5.4 Compressor lube oil sample 10. 5.5 Cooling fan hydraulic oil sample (where required) 11. 5.6 Engine coolant sample coolant concentration and conductivity test	
9. 5.4 Compressor lube oil sample 10. 5.5 Cooling fan hydraulic oil sample (where required) 11. 5.6 Engine coolant sample coolant concentration and conductivity test	
10. 5.5 Cooling fan hydraulic oil sample (where required) 11. 5.6 Engine coolant sample coolant concentration and conductivity test	
10. required) 11. 5.6 Engine coolant sample coolant concentration and conductivity test	
and conductivity test	
and conductivity test	
12. 5.7 Engine lube oil sample	
13. 5.8 Engine lube oil sample fuel oil dilution test	
14. 5.9 Governor lube oil sample	
15. 5.10 Traction motor suspension bearing lube oil	
sample	
5.11 Engine and fan room	
16. 5.12 Assessment	
examine	
all clamps for defects and security	
engine main generator compressor mounting areas	
engine room internally for fractures or other damage	
radiator access ceiling panels for cracks dents and alignment	
17. 5.13 Cover hatches and seals	
examine	
air box and crankcase inspection covers and	
sealing surfaces	
car body doors hatches and sealing surfaces secure	
18. 5.14 Cooling fan (where required)	
examine with engine shut down	
cooling fan condition and operation	
drive couplings on cooling fan motor	
drive couplings on hydraulic pump	
19. 5.16 Engine inspection	
examine with engine shut down	
cylinder test valves open to test for liquid	
accumulations in cylinder prior to starting engine	
evidence of external fuel oil or water leaks from	
cover seals filters pipe connections pipe work or	
water pump	
20. 5.17 Engine noise inspection	
examine operation with engine running at idle	
engine compressor and engine accessories for	
unusual knocks odours sounds or vibration	



A=U	INFIT FOR SERVICE	B= FOR FUTURE ATTENTION	C)= F	IT F	OR S	SERVICE	D= NOT APPLICABLE
	Cho	cklist	ΙΛ	В	С	D	<u> </u>	omments/Remarks
5 Pro	e-inspection	CKIIST	Α	Ь	C	U	C	omments/Remarks
	efects examination							
	s a general examination	of locomotive cab/s						
		partment engine and fan room						
		es and brake equipment to						
	e any broken loose or d							
21.	5.18 Fuel oil water and	l exhaust leak inspection						
	examine operation with	n engine running at idle						
		manifold to block joints						
		mps cracked or faulty stacks						
	exhaust boxes and bel							
		t glass or suction side of fuel						
	pump							
		in pipes engine blowers filters						
		system pipe work turbos						
		nt tank pipe joint gaskets						
22.	pipe work and water pu							
22.	5.20 Fuel injection line	d condition of equipment			l	l		
	leakage and vibration	condition of equipment						
23.	5.21 Fuel oil pressure							
25.		ered into log book is below						
		or shows a rapid decline of						
		period record for further						
	attention							
24.	5.22 Low tension earth	ns .						
	examine operation with	n engine running at idle all						
		est for low tension earths						
25.	5.24 Muffler box and s	park arrestor						
		d condition of equipment						
26.	5.25 Turbo/supercharg				1	1		
		d condition of equipment						
		plower pressure entered in log						
		elow specification kpa (psi)						
	record for further atten							
27.	5.26 Generator room/c 5.27 Assessment	control compartment						
21.		d condition of equipment			l	l		
		igns of overheating and						
	general condition	igns of overneating and						
		gns of overheating and						
	general condition	grio or overrioding and						
		f overheating and general						
	condition	3 4 4 3 4 4						
	condition and security	of hasler current apparatus						
		ent door seals and locks						
	5.28 Systems operatio							
		n field switch off with engine						
	running at throttle noto	h 3						
28.	5.28.1 Air system							
29.	5.28.2 Cooling system							
30.	5.28.3 Engine fuel oil s	system						

Version No:1.0Approved By:DirectorsVersion Date:30/04/2020Custodian:Rail Safety ManagerReview Date:30/04/2023

31. 5.28.4 Engine lube oil system/s



Page 5 of 31

32.	5.28.5 Governor and speed control			
33.	5.29 Support systems leakage inspection			



A=UNFIT FOR SERVICE B= FOR FUTURE ATTENTION C= FIT FOR SERV	CE D= NOT APPLICABLE
---	----------------------

Checklist 6 Drivers cab/generator room/control compartment 6.1 Log book report record any defects reported by the driver and entered in the locomotive log book for further attention defects should be repaired prior to locomotive being released to service 6.2 Cab 34. 6.3 Automatic and independent brake valve examine operation 35. 6.4 Brake pedestal isolating cock examine operation 36. 6.5 Cab accessories test operation and connections for tightness cab fans heaters and hotplate 37. 6.6 Controller and control stand (both sides) remove covers and examine operation 38. 6.7 Doors and windows examine operation	
6.1 Log book report record any defects reported by the driver and entered in the locomotive log book for further attention defects should be repaired prior to locomotive being released to service 6.2 Cab 34. 6.3 Automatic and independent brake valve examine operation 35. 6.4 Brake pedestal isolating cock examine operation 36. 6.5 Cab accessories test operation and connections for tightness cab fans heaters and hotplate 37. 6.6 Controller and control stand (both sides) remove covers and examine operation 38. 6.7 Doors and windows	
record any defects reported by the driver and entered in the locomotive log book for further attention defects should be repaired prior to locomotive being released to service 6.2 Cab 34. 6.3 Automatic and independent brake valve examine operation 35. 6.4 Brake pedestal isolating cock examine operation 36. 6.5 Cab accessories test operation and connections for tightness cab fans heaters and hotplate 37. 6.6 Controller and control stand (both sides) remove covers and examine operation 38. 6.7 Doors and windows	
the locomotive log book for further attention defects should be repaired prior to locomotive being released to service 6.2 Cab 34. 6.3 Automatic and independent brake valve examine operation 35. 6.4 Brake pedestal isolating cock examine operation 36. 6.5 Cab accessories test operation and connections for tightness cab fans heaters and hotplate 37. 6.6 Controller and control stand (both sides) remove covers and examine operation 38. 6.7 Doors and windows	
defects should be repaired prior to locomotive being released to service 6.2 Cab 34. 6.3 Automatic and independent brake valve examine operation 35. 6.4 Brake pedestal isolating cock examine operation 36. 6.5 Cab accessories test operation and connections for tightness cab fans heaters and hotplate 37. 6.6 Controller and control stand (both sides) remove covers and examine operation 38. 6.7 Doors and windows	
released to service 6.2 Cab 34. 6.3 Automatic and independent brake valve examine operation 35. 6.4 Brake pedestal isolating cock examine operation 36. 6.5 Cab accessories test operation and connections for tightness cab fans heaters and hotplate 37. 6.6 Controller and control stand (both sides) remove covers and examine operation 38. 6.7 Doors and windows	
6.2 Cab 34. 6.3 Automatic and independent brake valve examine operation 35. 6.4 Brake pedestal isolating cock examine operation 36. 6.5 Cab accessories test operation and connections for tightness cab fans heaters and hotplate 37. 6.6 Controller and control stand (both sides) remove covers and examine operation 38. 6.7 Doors and windows	
34. 6.3 Automatic and independent brake valve examine operation 35. 6.4 Brake pedestal isolating cock examine operation 36. 6.5 Cab accessories test operation and connections for tightness cab fans heaters and hotplate 37. 6.6 Controller and control stand (both sides) remove covers and examine operation 38. 6.7 Doors and windows	
examine operation 35. 6.4 Brake pedestal isolating cock examine operation 36. 6.5 Cab accessories test operation and connections for tightness cab fans heaters and hotplate 37. 6.6 Controller and control stand (both sides) remove covers and examine operation 38. 6.7 Doors and windows	
35. 6.4 Brake pedestal isolating cock examine operation 36. 6.5 Cab accessories test operation and connections for tightness cab fans heaters and hotplate 37. 6.6 Controller and control stand (both sides) remove covers and examine operation 38. 6.7 Doors and windows	
examine operation 36. 6.5 Cab accessories test operation and connections for tightness cab fans heaters and hotplate 37. 6.6 Controller and control stand (both sides) remove covers and examine operation 38. 6.7 Doors and windows	
36. 6.5 Cab accessories test operation and connections for tightness cab fans heaters and hotplate 37. 6.6 Controller and control stand (both sides) remove covers and examine operation 38. 6.7 Doors and windows	
test operation and connections for tightness cab fans heaters and hotplate 37. 6.6 Controller and control stand (both sides) remove covers and examine operation 38. 6.7 Doors and windows	
cab fans heaters and hotplate 37. 6.6 Controller and control stand (both sides) remove covers and examine operation 38. 6.7 Doors and windows	
37. 6.6 Controller and control stand (both sides) remove covers and examine operation 38. 6.7 Doors and windows	
remove covers and examine operation 38. 6.7 Doors and windows	
38. 6.7 Doors and windows	
examine operation	
39. 6.8 Emergency shutdown	
test operation	
40. 6.9 Fire extinguisher	
examine condition	
fire extinguishers inspection/date	
fire extinguishers present and fully charged	
stamp inspection tag to indicate inspection/date	
performed	
41. 6.11 Hand brake operation	
remove covers and examine operation	
lightly lubricate specification lubricant	
42. 6.12 Hasler speed recorder	
remove covers and examine operation	
set hands and wind clock	
replace diagram roll if necessary	
43. 6.13 Hasler speed recorder	
reduce brake pipe pressure to zero before closing	
instrument case after installing new diagram roll to	
ensure stylus is correctly positioned	
44. 6.14 Horns	
test operation and condition of equipment	
45. 6.15 Lights	
test operation and condition of equipment	
cab lights gauge lights	
coupler lights headlights (high & low beam) marker	
lights number lights step lights	
46. 6.16 Miscellaneous controls	
remove covers and examine operation	
battery charging ammeter	
engine control switch	
start and stop buttons	
47. 6.17 Pressure gauges	
examine operation and pressures	
cross reference readings between two control	



Page 7 of 31

stands			



		•	
A=UNFIT FOR SERVICE	B= FOR FUTURE ATTENTION	C= FIT FOR SERVICE	D= NOT APPLICABLE

	Checklist	Α	В	С	D	Comments/Remarks
C Dai				U	ט	Comments/Nemarks
	vers cab/generator room/control compartment					
	og book report					
recor	d any defects reported by the driver and entered in					
the lo	ocomotive log book for further attention					
	defects should be repaired prior to locomotive being					
	released to service					
40	6.19 Sanders/de-sanders operation and sandpipe					Form
48.	heights					FOIIII
	test operation and condition of equipment each					
	direction					
	service sand level					
49.	6.20 Train radio					
	test operation and condition of equipment					
50.	6.21 Vigilance control equipment					
	test operation and condition of equipment					
51.	6.22 Windscreen wipers					
	test operation and condition of equipment					



A=l	JNFIT FOR SERVICE	B= FOR FUTURE ATTENTION	C= FIT FOR SERVICE D= NOT APPL				D= NOT APPLICABLE	
	Che	cklist	Α	В	С	D	С	omments/Remarks
	6.23 Generator room/o	control compartment						
52.	6.24 Assessment							
	examine							
	all ht connections for s general condition	igns of overheating and						
	all It connections for si general condition	gns of overheating and						
	all resistors for signs o	f overheating and general						

	6.23 Generator room/control compartment			
52.	6.24 Assessment			
02.	examine			
	all ht connections for signs of overheating and			
	general condition			
	all It connections for signs of overheating and			
	general condition			
	all resistors for signs of overheating and general			
	condition			
	condition and security of hasler current apparatus			
	condition of compartment door seals and locks			
53.	6.25 Auxiliary contactors and relays			
00.	remove covers and examine operation			
	condition and cleanliness of equipment and all			
	connections			
54.	6.26 Body side air filters			
	remove clean and replace/new filters if necessary			
55.	6.27 Charging rate			
	test operation and condition of equipment			
	auxiliary generator charging rate			
56.	6.28 Control air reservoir			
	examine operation full main reservoir air maintained			
	open drain cock on control air reservoir and blow			
	any condensate from system			
57.	6.29 Electrical cabinet doors and seals			
	examine operation		T	
58.	6.30 Electro-magnetic contactors			
	ensure battery switch is open when cleaning filing or			
	operating electromagnetic contactors			
	remove covers and examine operation			
59.	6.31 Electro-pneumatic contactors			
	remove covers and examine operation			
	6.32 Exciter and auxiliary generator drive shaft			
60.	(main alternator and auxiliary alternator where			
	required)			
	examine			
	auxiliary generator drive shaft coupling bushings			
	and bolts for evidence of fatigue			
61.	6.33 Exciter and auxiliary generator coupling (main			
01.	alternator and auxiliary alternator where required)			
	examine			
	auxiliary generator coupling flexible coupling plate			
	for evidence of fatigue			
62.	6.34 Exciter and auxiliary generator (main alternator			
υ <u>∠</u> .	and auxiliary alternator where required)			
	remove machine covers and examine operation			
	replace any brushes which are broken or worn			
	examine waste sump and remove any foreign		1 7	
	matter which may result in a blockage of drain pipe			

6.40 Systems operation inspection motors (and

auxiliary equipment)

6.40.1 Cleaning

6.40.2 Integrity

6.40.3 Lubrication

6.40.4 Noise and vibration

6.40.5 Supply voltage

6.40.6 Identification

72.

73.

74.

75.

76.

77.



A=l	JNFIT FOR SERVICE	B= FOR FUTURE ATTENTION	C= FIT FOR SERVICE D= NOT AP		D= NOT APPLICABLE			
	Checklist		Α	В	С	D	С	omments/Remarks
	6.23 Generator room/c	ontrol compartment						
63.	6.35 Motors (auxiliary e	equipment where required)						
	remove covers and exa							
	drive couplings for wea	ar or other damage						
		hich are broken or worn						
64.	6.36 Miscellaneous							
	examine							
	all magnet valves							
	all pressure switches							
65.								
	remove covers and exa	amine operation						
66.	6.38 Traction generato	r						
	remove machine cover	s and examine operation						
	replace any brushes w	hich are broken or worn						
		and remove any foreign						
	matter which may resu	It in a blockage of drain pipe						
	6.39 Systems operatio	n inspection motors (and						
	auxiliary equipment)							
67.	6.39.1 Visual inspectio	n						
68.	6.39.2 Brush and comr	mutator inspection						
69.	6.39.3 Bearings inspec	etion						
70.	6.39.4 Vibration test							
71.	6.39.5 Infrared thermo	graphy camera			,			

Version No: 1.0 Approved By: Directors Version Date: 30/04/2020 Custodian: Rail Safety Manager 30/04/2023 Review Date: Page 10 of 31



A=L	INFIT FOR SERVICE	B= FOR FUTURE ATTENTION	C	C= F	IT F	OR S	SERVICE	D= NOT APPLICABLE
	01	12.4	۱ ۵					. /5
7 -		cklist	A B C D Comments/R		omments/Remarks			
	gine and fan room							
78.	7.1 Assessment							
	examine	and a country						
	all clamps for defects a							
		compressor mounting areas						
		for fractures or other damage						
	alignment	panels for cracks dents and						
79.	7.2 Air vane							
	test operation with eng	ine running at idle						
80.	7.3 Air strainers							
	remove clean and repla							
		ssor governor control air						
	vigilance control whistl	e valve and sanders						
81.	7.4 Batteries							
		d condition of equipment						
	battery box assembly r							
	examine leads and cle							
	conduct battery condition discharge test							
	maintain water level at (12mm)	oove splash barrier ½"						
82.	7.5 Body side air filters							
02.		ace/new filters if necessary						
83.	7.6 Compressor	acomow interest incoopering						
- 00.		amine operation with engine						
	drive couplings on com	npressor motor						
84.	7.7 Compressor	•						
	remove covers and ex- running at idle compre-	amine operation with engine						
	airlines and safety valv	ves for damage or indications						
	of air or oil leaks	r gauge aposition to						
0.E		r gauge specification kpa						
85.	7.8 Compressor air inta	ake filters ace/new filters if necessary						
06								
86.	7.9 Compressor breath	iei		1	I			
	remove and replace	ionbroam/ronloop if						
	examine condition of d necessary							
87.	7.10 Compressor cran							
	remove clean and repla							
	with compressor lube oil drained clean crankcase interior							
88.								
		condition of equipment						
	compressor drive coup							



A=L	INFIT FOR SERVICE	B= FOR FUTURE ATTENTION	(C= F	IT F	OR S	SERVICE	D= NOT APPLICABLE
	Cho	cklist	Ι Λ	В	С	D		omments/Remarks
7 En	gine and fan room	CKIISt	Α	D	C	טו		omments/Remarks
89.	7.12 Compressor gove	arnor		_	_	_		
03.		d condition of equipment						
	clean and drain compr							
	adjust pressure setting							
		ernor and adjust pressure						
		veen specification kpa (psi)						
	115-125psi (800-860kg							
90.		cooler/intercooler safety valve						
		d condition of equipment						
	drain condensate							
	operate intercooler saf	ety valve ensure						
	function/operation	•						
91.	7.14 Compressor lube	oil						
	remove clean and repl	ace change lube oil						
92.	7.15 Compressor lube							
		amine operation of indicator						
	or gauge with engine r	unning at idle compressor						
	running							
gaug	e reading							
		specification kpa (psi)						
93.	7.16 Compressor orific	ce test						
	test operation							
94.	7.17 Compressor unloa valves	aders valves and safety						
	examine operation and	d condition of equipment						
	examine operation all	safety valves specification						
	kpa (psi)							
		specification kpa (psi)						
	1	if necessary specification						
05	lubricant							
95.	7.18 Cooling fan (wher							
	examine operation with							
	lubricate bearings if ne lubricant	ecessary specification						
	hydraulic oil level							
	add specification hydra	aulic oil if necessary						
		rulic oil by-pass filter (where						
96.	required)	idile on by page inter (where						
	remove clean and repl	ace		Π				
	replace filter							
07	7.26 Cooling fan hydra	ulic oil full-flow filter (where						
97.	required)	•						
	remove and replace							
	replace filter inside tan	k						
98.	7.27 Crankcase cranks							
50.	inspection							
		d condition of equipment						
	lube oil level							
	add specification lubric							
99.	7.28 Crankcase breath	ner					I	



remove clean and replace			



A=U	INFIT FOR SERVICE	B= FOR FUTURE ATTENTION	C	C= F	IT FO	OR S	SERVICE	D= NOT APPLICABLE
	Che	cklist	Α	В	С	D	C	omments/Remarks
7 Eng	gine and fan room							
100.	7.35 Engine air filters a	and filter minder						
	examine operation and condition of equipment							
	replace filters if necess	sary						
101.	7.36 Engine air filters a	and filter minder filter indicator						
	examine operation and	d condition of equipment						
	filter minder for indicati	ion of engine air filter service						
	indicator	-						
102.	102. 7.38 Engine valve rotators							
	examine with engine running at idle							

	Checklist	$^{\wedge}$	Ь	٥	ט	Comments/Nemarks
7 Eng	gine and fan room					
100.	7.35 Engine air filters and filter minder					
	examine operation and condition of equipment					
	replace filters if necessary					
101.	7.36 Engine air filters and filter minder filter indicator					
	examine operation and condition of equipment					
	filter minder for indication of engine air filter service					
	indicator					
102.	7.38 Engine valve rotators					
	examine with engine running at idle					
103.	7.39 Engine valve settings					
	examine with engine cold					
	exhaust valve specification clearance 0.035"					
	(0.9mm)					
	inlet valve specification clearance 0.015" (0.38mm)					
104.	7.42 Exhaust stack/spark arrestor		1			
	examine operation and condition of equipment					
105.	7.43 Fuel oil filters primary and secondary					
	remove clean and replace					
	clean strainer with suitable cleaning agent					
	examine for leaks and fuel pressure is in correct					
	range					
106.	7.44 Fuel oil filters primary and secondary					
	remove clean and replace					
	replace filters					
	examine for leaks and fuel pressure is in correct					
	range					
107.	7.46 Fuel oil pump drive coupling (where required)					
	examine operation and condition of equipment					
	fuel oil pump drive coupling for wear or other					
	damage					
108.	7.47 Fuel oil pump crankcase exhauster and starter					
	motors					
	remove covers and examine condition	-			-	
	replace any brushes which are broken or worn				ļ	



A=U	NFIT FOR SERVICE	B= FOR FUTURE ATTENTION	C= FIT FOR SERVICE D= NOT			D= NOT APPLICABLE		
	Che	cklist	Α	В	С	D	Co	omments/Remarks
7 Eng	gine and fan room							
109.	7.50 Governor							
	remove covers and exa	amine operation						
	plug wash plug and red	ceptacle						
110.	7.51 Governor							
	remove covers and exa running at idle	amine operation with engine						
	lube oil level							
	add specification lubric							
111.	7.53 Holding down bolt	s						
	examine mountings for broken damaged or loose bolts and dowels tightness							
112.	7.54 Hoses							
	examine operation and condition of equipment							
	replace if necessary	• •						
113.	7.55 Hydraulic system	(where required)						
		condition of equipment						
	hydraulic system for le	aks						
114.	7.58 Lube oil filters							
	remove covers and exa	amine operation						
	replace lube oil filters							
	examine for leaks and range	lube pressure is in correct						
115.	7.59 Lube oil filter sepa	arator screen			l			
	remove clean and repla	ace lube oil filter separator						
	screen							
	examine for leaks and lube pressure is in correct range							
116.	6. 7.60 Lube oil pressure							
	examine operation with engine running at idle							
reading is above 30Psi (207kPa)								
gaug	e reading idle							

Version No: 1.0 Approved By: Directors Version Date: 30/04/2020 Custodian: Rail Safety Manager 30/04/2023 Review Date: Page 15 of 31

specification kpa (psi)

specification kpa (psi)

gauge reading throttle notch 8

7.61 Lube oil strainer

remove clean and replace lube oil strainer

117.

124.

125.

126.

127.

belt condition and tension

lubricant if necessary

correct belts tension

traction motor blower belts

operation

necessary

drained

remove covers and examine operation

depress belts one at a time in center

7.69 Traction motor blower spicer shaft remove covers and examine operation spicer shaft coupling traction motor blower lubricate if necessary specification lubricant

7.70 Traction motor cooling duct air flow examine operation with engine running at idle traction motor cooling duct positive air flow

7.73 Waste removal and waste sumps ensure all waste sumps (bilge) are clear and

traction motor blower rotor/impeller condition and

shaft bearing housing add specification lubricant if

idler/jockey pulley bearings add specification



Page 16 of 31

A=U	JNFIT FOR SERVICE	ATTENTION	C= FIT FOR SERVICE D= NOT APPLICAL				D= NOT APPLICABLE	
	Checklist		Α	В	С	D	C	omments/Remarks
	7 Engine and fan room							
118.								
	remove covers and ex	amine operation						
		ngine room and fan room						
	including de-sanding n	nagnet valves						
		meter and thermostatic						
	switches in engine roo							
	low water cut out switch	h and float switch						
	pressure switch in eng							
119.								
	examine operation and	d condition of equipment						
120.	7.64 Muffler box drains	5						
	examine operation and	d condition of equipment						
	remove muffler box dra	ain pipe						
	ensure pipe and conne	ection are clear						
	drain residue							
121.	7.65 Piston connecting	rod and cylinder liner						
121.	inspection	•						
	examine operation and	condition of equipment						
122.	7.66 Piston cooling pip							
	examine operation and	condition of equipment						
	piston cooling oil pipes							
	misalignment							
123.	7.67 Traction motor blo	ower rotor/impeller						_
	remove covers and ex-	amine operation						_
	remove any deposits fi	rom rotor/impeller with clean						
	lint free cloth	- -						
124	7.68 Traction motor blo	ower rotor/impeller bearings						_

Approved By: 30/04/2020 Version No: 1.0 Directors Version Date: Custodian: Rail Safety Manager Review Date: 30/04/2023





A=U	INFIT FOR SERVICE	B= FOR FUTURE ATTENTION	C= FIT FOR SERVICE D= NOT APPLICABLE					
	Cha	aldiat	Ι Δ	В		_		a na ma a mata /D a ma a mil ca
0.116	derneath locomotive	cklist	Α	В	С	D	C	omments/Remarks
		a a lua						
128.	8.4 Air reservoir drain					ı		
		I condition of equipment	-					
	and reservoirs	all dirt collectors intercoolers						
129.	8.5 Automatic couplers	and draft dear						
129.	examine condition adju							
130.	8.6 Axle box pedestal l							
130.								
		condition of equipment						
404		specification clearances						
131.	8.7 Axle box roller bea					Г		
		condition of equipment						
	axle box bearing lubric unit installation date	ate date bearing package						
		racks lubricant leakage or						
	other damage	rache rabilitatii loanage oi						
	wear liners for cracks b	proken or cracked welds or						
	wear							
132.								
	examine operation and	condition of equipment						
	bogie code number an on side frames	d lift due date clearly painted						
		nponents side frames stop						
		uffer plates brake cylinder						
		ects or fractures freedom of						
	movement security and							
		r plates side bearers spring						
		ractures security and wear						
		bushes and split pins for						
	defects or fractures se							
133.		ng plates and loading pads						
		I condition of equipment						
		thrust plate dust guards and						
	drain							
	centre bearing castings							
	•	ant if necessary to filler						
	aperture							
134.	8.10 Bogie mounted si dampers	nock absorbers/vibration						
		I condition of equipment						
	assembly mounting for							
	vertical transom dampe	ers clevis rods for condition						
	and leakage							
		for condition and leakage						
	all rubbers security and	d wear						
								· · · · · · · · · · · · · · · · · · ·



A=U	NFIT FOR SERVICE	B= FOR FUTURE ATTENTION	C	D= NOT APPLICABLE				
		cklist	Α	В	С	D	C	omments/Remarks
	derneath locomotive							
135.								
		l condition of equipment						
136.	8.12 Brake cylinders/sl adjusters	ack adjusters-hand slack						
	examine operation and	condition of equipment						
	assembly mounting for							
	lubricate all brake cylin	ders/slack adjusters-hand						
	slack adjusters with gre							
	lubricant (or into each							
137.	8.13 Brake cylinder pis							
	examine operation and	I condition of equipment						
	set brake piston travel							
138.	8.14 Brake rigging							
		l condition of equipment						
139.	8.16 Distributing valve							
	examine operation							
	distributor valve/triple v							
	distributor valve/triple valve/	valve assembly mounting for						
	clean and lubricate specification lubricant							
	centrifugal dirt collector/dust strainer							
	clean collector/ straine	r new gasket if required						
	operation and release							
140.	8.17 Fuel tank examina	ation						
	examine operation and	condition of equipment						
	drain condensation from	m fuel tank						
	record fuel level							
		Itrs						
141.	8.18 Hasler speed reco	order transmitter						
	remove covers and exa	amine condition						
	replace any brushes w	hich are broken or worn						
	lubricate transmitter ca	ble and drive specification						
142.	8.19 Holding down bolt	ts						
	examine mountings for bolts and dowels tightn	broken damaged or loose						
	air reservoir tank/s							
	fuel tank							
143.	8.20 Jumpers and jump	per receptacles						
		condition of equipment						
144.	8.24 Traction motors	, ,						
		s and examine operation						
		hich are broken or worn						
145.	8.25 Traction motor ax							
	examine condition							
146.								
	examine condition							
147.	8.27 Traction motor ge	ar case and seal						
	examine condition							
148.	8.28 Traction motor ge	ar case lubricant drain						
	examine							



					1	
1			- 1			
			1			



A=UNFIT FOR SERVICE	B= FOR FUTURE ATTENTION	C= FIT FOR SERVICE		SERVICE	D= NOT APPLICABLE		
Che	ecklist	Α	В	С	D	С	omments/Remarks
8 Underneath locomotive							
149. 8.29 Traction motor g	ear case lubricant levels						
examine							
	add specification lubricant if necessary maintain						
heavy film on gear tee	heavy film on gear teeth						
150. 8.30 Traction motor ne	150. 8.30 Traction motor nose suspension						
examine condition							
151. 8.32 Traction motor si	uspension bearing oil level						
examine							
drain condensation fro	m suspension bearing wells						
fill sump to correct lev	fill sump to correct level specification lubricant						
152. 8.36 Under frame	152. 8.36 Under frame						
examine condition	_						
153. 8.37 Wheel examinati	on					Form	
examine condition							
	•						





A=L	A=UNFIT FOR SERVICE B= FOR FUTURE ATTENTION		(C= FIT FOR SERVICE				D= NOT APPLICABLE
	Che	cklist	Α	A B C D C		С	omments/Remarks	
9 Ge	neral with engine shutdo	own						
	9.1 Engine and fan roo	om						
154.	9.2 Governor low lube	alarm						
	test operation							
155.	9.3 Low tension earth							
	test operation							
	battery switch closed all circuit breakers and switches closed							
	test both sides of switch	h for low tension earth fault						
156.	9.4 Megger test							
	test operation							
	open and inspect grou	nd relay cut out knife switch						
	test high tension syste	m						
157.	9.5 Propulsion control	test						
	test operation							
158.	·	est						
	test operation							
	manually operate relay	ı/s						
	, ,			1	1			

Approved By: Version No: 1.0 Directors Version Date: 30/04/2020 Custodian: Rail Safety Manager Review Date: 30/04/2023 Page 23 of 31





A=U	NFIT FOR SERVICE	B= FOR FUTURE ATTENTION	C)= F	IT FO	OR S	SERVICE	D= NOT APPLICABLE
		cklist	Α	В	С	D	С	omments/Remarks
	eneral with engine runni	ng						
159.	10.1 Assessment				I			
		n engine running at idle						
	all fuel line assemblies							
	any obvious fuel oil or							
	valve assemblies and	supplied to camshaft bearings rocker gear						
	mechanical componen	ts are receiving lubrication						
	obvious unusual knock	s odours sounds or vibration						
	from compressor engir	ne or generator						
	10.2 Assessment							
160.	10.3 Cover hatches an							
	examine operation with notch eight	n engine running at throttle						
	air box and crankcase sealing surfaces	inspection covers and						
		s and sealing surfaces secure						
	10.4 Assessment							
161.	10.5 Engine inspection							
		n engine running at idle						
		el oil or water leaks from						
	cover seals filters pipe	connections pipe work or						
	water pump							
162.	10.6 Engine noise insp							
	examine operation with engine running at idle							
	engine compressor and unusual knocks odours	d engine accessories for						
163.		exhaust leak inspection						
105.		n engine running at throttle						
	notch eight							
	exhaust leakage from							
		mps cracked or faulty stacks						
	exhaust boxes and bel							
	pump	glass or suction side of fuel						
		n pipes engine blowers filters system pipe work turbos						
	water leaks from coola	nt tank pipe joint gaskets						
164.	pipe work and water pu 10.8 Brake cylinder pre							
104.	test operation	essure switch			l			
165.	10.9 Compressor oper	ation						
100.		n engine running at idle main						
		ble between 110-120psi (750-						
		er than 40 seconds to pump						
166.	10.10 Engine coolant							
100.	examine coolant level	n tank						
		on coolant if necessary						
		igine dead or full engine					1	
	running mark on sight							
gaug	e reading green band							



Page 26 of 31

	specification temperature			
167.	10.13 Engine coolant temperature regulators			
	examine coolant level in tank			
	examine coolant temperature at specification			
	temperature			
			,	



					Т	
A=UNFIT FOR SERVICE	B= FOR FUTURE ATTENTION	C= FIT FOR SERVICE		RVICE	D= NOT APPLICABLE	
						-
	cklist	A B	С	D	C	omments/Remarks
10 General with engine runni						
168. 10.14 Engine lube oil le						
	n engine running at idle at					
temperature						
	mark on bayonet gauge					
	on lubricant if necessary					
169. 10.15 Engine lube oil p						
	n engine running at idle					
reading is above 30Ps	i (207kPa)					
170. 10.16 Engine speeds						
test operation with eng	ine running at idle					
171. 10.17 Engine over-spe						
test operation with eng						
	172. 10.18 Fuel oil pressure					
gauge reading green band	specification kpa (psi)					
173. 10.19 Governor	opecinication that (poly					
	amine operation with engine		Т			
running at idle	annie operation mit engine					
examine lube oil level						
add specification lubric	ant if necessary					
174. 10.20 Ground relay			_			
test operation with eng	ine running at idle		Т			
175. 10.21 Hot engine alarn			_			
test operation with eng			Т			
176. 10.22 Low lube oil shu			_			
test operation with eng			Т			
177. 10.23 Low water alarm						
test operation with eng						
178. 10.24 Low tension volt						
test operation with eng						
179. 10.25 Wheel slip	arrining ac idio		_			
	ine running at idle air brakes					
and hand brake applie						
and hand brane applie	-	+ +	+			-

Approved By: Version No: 1.0 Directors Version Date: 30/04/2020 Custodian: Rail Safety Manager Review Date: 30/04/2023 Page 27 of 31



A=U	NFIT FOR SERVICE	B= FOR FUTURE ATTENTION	C	= FI	T F	OR S	SERVICE	D= NOT APPLICABLE
	Cha	aldiat	Ι Δ	Ь		<u> </u>		a mana anta /D a ma a ul ca
11 0		cklist	Α	В	С	D	C	omments/Remarks
	peration check	anta avamina aparation of						
	notive controls	ents examine operation of						
100011	11.1 Cab							
180.	11.4 Vigilance control	aguinment						
100.	test operation	equipinient						
	11.5 Engine and fan ro	om						
181.	11.6 Ground relay test	OIII						
101.	test operation							
182.	11.7 Seals							
102.	remove and replace							
		nd relay cut out knife switch						
		relay cut out knife switch						
	standard lead seal and							
	seal vigilance control b							
183.	11.8 Transition test	<u> </u>						
100.	test operation							
184.	11.9 Wheel slip test							
	test operation							
	11.10 Underneath loco	motive						
185.	11.11 Air brake operati						Form	
	test operation							
		em operation test (safety air						
	brake test)	m operanem toot (carety an						
186.	11.12 Emergency kit							
	ensure complete							
12 Fi	nal running check							
187.	examine operation of lo	ocomotive						
400		shes are bedded in (noted						
188.	on maintenance record							
100	all foreign materials to	be removed from locomotive						
189.	(e.g. paper rags tools)							
190.	all covers correctly pos	itioned						
191.	all locomotive doors clo	osed						
192.	emergency kit complet	e						
193.	relevant documentation	n completed						
194.	12.1 Inspections/maint							
		ate date bearing package]					
	unit installation date						Record date	Э
		d lift due date clearly painted					D	
	on side frames		+				Record date	9
	brake cylinder lubricate	e date 'bc' due date					Record date	е
	distributor valve/triple v	alve 'tv' due date					Record date	Э
	fire extinguishers inspe	ection/date						
	3						Record date	5



Lagamativa Number		Data					
Locomotive Number		Date					
Details of other repairs	Details of other repairs carried out						
Details of outstanding w	vork						

THIS DOCUMENT IS UNCONTROLLED WHEN PRINTED



Locomotive Number		Date		
Materials used				
Material	Unit		Quantity	
Compressor Oil	Litres			
Engine Oil	Litres			
Governor Oil	Millilitres			
Cooling Water	Litres			
Hydraulic Oil	Litres			
Journaltex	Litres			
Globes	74V 10W			
	74V 40W			
	Headlights			
	Hasler Globes			
Hasler Tapes				
Brake Shoes	Cast/Composite			
Sand Bags	15kg			
Crater Grease				
Other materials used				
_				



	LOCOMOTIVE FIT FOR SERVICE	
NAME	SIGNATURE	DATE
REMARKS		
REMARKS CONTINUOUS IMPROVE	MENT (suggested changes to form/s)	

Version No: